

NIAGARA 3000UK

Low-Z Power | Noise-Dissipation System

Quick-Start Guide




The Niagara 3000UK owner's manual contains considerable information to ensure optimal performance, troubleshoot both common and rare system interactions, and is a great primer to the technology that makes this unit so unique. However, we appreciate and respect your valuable time. At the very least, we humbly ask that you follow this quick-start guide.

- If the Niagara 3000UK has been exposed to excessive rain, flooding, fire, or has sustained considerable physical damage, we ask that the unit be returned. Do not attempt to energize the unit or connect equipment to it!
- For proper operation, the Niagara 3000UK requires a safety ground (supplied via the power utility AC wall outlet).
- The Niagara 3000UK may be placed on any table, cabinet, shelf, or floor. When rack-mounting is required, the four threaded feet may be removed with a standard Phillips screwdriver. A rack-mounting kit and instructions are included with the unit.
- Placement or proximity to other components is not critical, and, under standard use, the Niagara 3000UK does not produce any appreciable heat.
- Once the Niagara 3000UK is placed, an appropriate 13 to 16-amp-rated (high-current) AC cord must be connected to the rear-panel AC inlet (IEC-C14) connector. The AC cord must have an IEC-C13 female-end connector and a grounded male UK1-13P plug for use in the UK and other appropriate countries that utilize this power connector for home and office use. For the best performance and proper Ground-Noise Dissipation, we recommend AudioQuest AC cords (2.5mm conductors and larger: at minimum, NRG-Z3; ideally, Monsoon through Hurricane).
- **High-Current/Low-Z Power Banks:** There are two High-Current/Low-Z Power outlets (labeled "1" and "2"). The outlets feature our Transient Power Correction Technology and are designed to enhance the performance of power amplifiers via our circuit's low-impedance transient current reservoir. Power amplifiers, monoblock amplifiers, integrated amplifiers, powered receivers, or powered subwoofers should *ideally* be connected to these two outlets. However, compared to its larger siblings, the Niagara 3000UK is unique. Even its **Source power** banks are capable of passing extraordinarily high transient current before soft-clipping (in excess of 50 amps peak). So, if you have one or two main power amplifiers and an additional one to two subwoofers, use the High-Current AC outlets for the power amps. The subwoofers will still yield great results when connected to any of the five AC source outlets.
- **Power Correction Switch:** This rear-panel-mounted switch **MUST** be set in the ENERGIZED/"1" position, regardless of the equipment (line-level, digital, video components, or power amplification) that is connected to the Niagara 3000UK. It may not function at full capacity otherwise. If necessary, see user manual set-up for more detailed information. (Otherwise, please place this switch in the **ENERGIZED/"1"** position.)
- **Level-X Linear Noise-Dissipation System Power Outlets:** Typically, these are for all line-level, digital, and video products. There are five outlets (labeled "3," "4," "5," "6," and "7") that utilize this technology within the Niagara 3000UK. Further, outlets "3," "4," and "5," and outlets "6" and "7," employ ground-noise isolation circuits that are independent from each other, and from the high-current banks.
- **I hear a slight buzzing sound coming from the Niagara 3000UK. Is it damaged?** No, it's not damaged (or, at least, damage is very unlikely). If you're in an extraordinarily quiet room and you hear this buzzing sound only when in relatively close proximity to the Niagara 3000UK, or only when you place your ear next to the unit, the buzzing is normal and cannot be entirely eliminated (though easily detectable levels are rare). See the Niagara 3000UK manual for detailed information about high-level harmonic AC line distortion and its ability to make some of the circuits suffer from mechanical ringing, or magnetostriction. The simple workaround is to set the rear panel switch to "0."

Suggested AC Connections


1

"Energized" position must be default setting.



2

"Energized" position must be default setting.



Note: Outlets 3 through 7 are subject to many variables and circuit conditions, so experimentation for best results is encouraged. Power amplifiers must be connected to outlets 1 or 2.